

CURTIS 之綜合儀表型號規格



照片	型號
	3100R / enGage® II
	3100T / enGage® III
	3140
	3501

 <p>A circular blue digital display with the brand name 'CURTIS' at the top. The screen shows 'MODEL 840' and several small icons below it, including a battery, a gear, and a light bulb.</p>	<p>840</p>
 <p>A rectangular digital display with a green screen. It features a speedometer needle, a battery level indicator, and various status icons. The number '35' is visible on the screen.</p>	<p>enGage® IV</p>
 <p>A rectangular digital display with a white screen. It shows a battery level indicator, a speedometer, and several warning icons. The text 'Mon 12:02 PM' and '11000RS SYNC' is visible at the bottom.</p>	<p>enGage® VI</p>
 <p>A rectangular digital display with a white screen. It features a large speedometer, a battery level indicator, and various status icons. The text '1400 S' and 'PHASE' is visible at the bottom.</p>	<p>enGage® VII</p>

